

How to Set Up and Use an AV Cart

By Luci Monk

Connect the projector to the computer using the blue RGB cable.

You will connect one end to input one on the projector and the other end to the video/monitor image on the laptop.



You will connect one end to input one on the projector and the other end to the video/monit or image on the laptop.



Video/
monitor
connectio
point



External
power supply
connection
point

Computer video/monitor connection point.

Connect the external power supply cable to the back of the laptop and then to the power strip on the side of the av cart

Connect DVD/VHS to audio/visual cable to output on DVD player



audio/visual cables



Connection point on back of DVD player

Connect the other end of the av cable (red, yellow & white) to the input on the projector



Connect the green speaker cable to the audio output on the projector

Connect external speakers to subwoofer and then to power strip on av cart



Connect computer to server/internet using the Ethernet cable. Connect the Ethernet cable to the wall port in your classroom.




Other important Info

- To connect external speakers to computer, unplug green speaker cable from projector and plug into the speaker output on the side of the computer.



Other Important Info

- When you turn on the av cart the VCR/DVD player and projector should automatically come on. If not, make sure the switch on the power strip is in the on position. You should see this image when it is on.



More Important Info

- To “boot up” the computer, press the power button located just under the DELL logo.
- Username: your network user name
- Password: Your network password



Press here to
“boot up” the computer.

**MAKE SURE
YOU LOG OFF
WHEN YOU ARE
FINISHED!**