

# Using Optoma ES522 Digital Projector With Multiple Media Devices

## Before You Begin

The Optoma ES522 is a portable digital projector that is easy to setup and use.


Connect media devices and follow the directions for powering on the device.

**Assumptions:**


Users know how to setup and use peripheral devices.



## Control Panel




**Rear View**



**Connecting VCR/DVD Player - Overview**

**Connecting** Magnavox DVD Player/VCR  
Model # DV220MW9



**Connecting VCR/DVD Player - Cables**



Cable to speakers  
(White & Red Cable)



**Connecting Laptop - Overview**

Video Output



Audio Output

## Connecting Laptop - Cabling

### Video



Laptop – Video Output



### Audio

Laptop –  
Audio  
Output



**SPEAKERS**

### ***Powering on the Projector***

1. Remove the lens cover of the projector.
2. Connect the power cord to the projector.
3. Connect the media device.
4. Turn on the media devices.
5. Verify the Power LED is flashing, press the power button.
6. If a PC is being used, assure the PC is setup for output to the projector.
7. If more than one device is being used, press the "Source" to toggle between the devices.
8. To focus the image, adjust the zoom/focus dial found on top of the projector.
9. To adjust the height of the image, press the elevator button found in front of the device.

### ***Powering off the Projector***

1. Press "Power" to turn off the projector.
2. A message will appear. Press "Power" a second time.
3. The cooling fans will continue to run for a short period of time.

**\*\* WARNING \*\*** Do not turn on the projector immediately following a power off procedure.